

# GATE | PSUs

## ELECTRONICS & COMMUNICATION ENGINEERING

## **Electronic Devices**

(**Text Book :** Theory with worked out Examples and Practice Questions)

Chapter

## **Basics of Semiconductors**

(Solutions for Text Book Practice Questions)

01. Ans: (a) **Sol:**  $N_D = 5 \times 10^{22} \times \frac{1}{10^9} \text{ cm}^{-3}$  $= 5 \times 10^{13} \text{ cm}^{-3}$ According to mass action law  $np = n_i^2$  $n_n p_n = n_i^2$  $N_D p_n = n_i^2$  (:: $n_n \simeq N_D$ )  $p_n = \frac{n_i^2}{N_n}$  $p_{n} = \frac{\left(1.5 \times 10^{10}\right)^{2}}{5 \times 10^{13}}$  $=4.5 \times 10^{6} \text{ cm}^{-3}$ 02. Ans: (b) **Sol:** According to law of mass action  $n.p = n_i^2$ Where  $n_i = intrinsic carrier concentration$ .  $N_D = doping$  concentration for n- type material. Majority carrier concentration Since  $n \cong N_D$  $p = \frac{n_i^2}{N_p}$  $p\alpha \frac{1}{N_p}$ 03. Ans: (b) Sol: V = 5VL = 100 mm $\mu_n = 3800 \text{ cm}^2/\text{V-sec}$  $\mu_p = 1800 \text{ cm}^2/\text{V-sec}$  $V_{dn} = \mu_n E$ India's Best Online Coaching Platform for GATE, ESE, PSUs, SSC-JE, RRB-JE, SSC, Banks, Groups & PSC Exams

 $= 3800 \times \frac{V}{I}$  $= 3800 \times \frac{5}{100 \times 10^{-1}}$ = 1900 cm/sec

## 04. Ans: (d)

Sol: For the n-type semiconductor with  $n = N_D$  and  $p = n_i^2 / N_D$ , the hole concentration will fall below the intrinsic value because some of the holes recombine with electrons. 05. Ans: (c) **Sol:**  $N_A = \frac{10^{15}}{1.6} \operatorname{acceptor}/\operatorname{cm}^3$  $\mu_n = 4000 \text{ cm}^2/\text{V-sec}$  $\mu_p = 2000 \text{ cm}^2/\text{V-sec}$  $\sigma_p = p q \mu_p$ =  $N_A q \mu_p$  (: 100% doping efficiency)  $=\frac{10^{15}}{1.6} \times 1.6 \times 10^{-19} \times 2000$ = 0.2 mho/cm06. Ans: (d) Sol: According to mass action law.

$$np = n_i^2$$

$$n_n p_n = n_i^2$$

$$n_p p_p = n_i^2$$

$$n_p N_A \simeq n_i^2$$

$$N_D p_n \simeq n_i^2$$

07. Ans: (a)

a

**Sol:**  $R_{\rm H} = 3.6 \times 10^{-4} \text{ m}^3/\text{c}$  $\rho = 9 \times 10^{-3} \Omega - m$ 

Let us consider n-type semiconductor

ace online

Enjoy a smooth online learning experience in various languages at your convenience

Engineering Publications	3 Postal Coaching Solutions
$R_{\rm H} = \frac{1}{nq}$ $n = \frac{1}{qR_{\rm H}} = \frac{1}{1.6 \times 10^{-19} \times 3.6 \times 10^{-4}}$ $= 1.736 \times 10^{22} \text{ m}^{-3}$	11. Ans: (c) Sol: $D_n = 20 \text{ cm}^2/\text{s}$ $\mu_n = 1600 \text{ cm}^2/\text{V-s}$ $\frac{D}{\mu} = \frac{kT}{q} = V_T$ $\Rightarrow V_T = \frac{20}{1600} = 12.5 \text{ mV}$
<b>08.</b> Ans: (b) <b>Sol:</b> At equilibrium No. of $e^-$ density = No. of hole density $\therefore$ given $e^-$ density is $n(x_1) = 10 n(x_2)$ $\Rightarrow n(x_1)$ is majority $\Rightarrow n(x_2)$ is minority $\therefore p(x_2) = 10p(x_1)$	12. Ans: (d) Sol: Conductivity of a semiconductor, $\sigma = (n\mu_n + p\mu_p)q$ Where, $\mu_n \rightarrow$ mobility of electrons $\mu_p \rightarrow$ mobility of holes $n \rightarrow$ electron concentration $p \rightarrow$ hole concentration
<b>09.</b> Ans: (b) <b>Sol:</b> $\rho_p = 3 \times 10^3 \Omega - m$ $\mu_p = 0.12 \text{ m}^2/\text{V-sec}$ $V_H = 60 \text{mV}$ $\rho_p = \frac{1}{\sigma_p}$ $3 \times 10^3 = \frac{1}{pq\mu_p}$ 1	q → electron charge 13. Ans: (c) Sol: N <sub>A</sub> = 2.29 × 10 <sup>16</sup> E <sub>Fi</sub> - E <sub>Fp</sub> = kT ln $\left(\frac{N_A}{n_i}\right)$ = 0.02586 ln $\left(\frac{2.29 \times 10^{16}}{1.5 \times 10^{10}}\right)$ = 0.3682 eV = 0.27 eV
$p = \frac{1}{3 \times 10^{3} \times 1.6 \times 10^{-19} \times 0.12}$ $P = 1.736 \times 10^{16} \text{ m}^{-3}$ $R_{H} = \frac{1}{pq} = \frac{1}{1.736 \times 10^{16} \times 1.6 \times 10^{-19}}$ $= 360 \text{ m}^{3}/\text{C}$ 10. Ans: (b) Sol: $J_{drift} = n\mu_{n}qE + p\mu_{P}qE$ $J_{drift} = [(n.q)\mu_{n} + (p.q)\mu_{p}]E$ $J_{drift} = [\rho_{n}\mu_{n} + \rho_{p}\mu_{p}]$ $J\alpha `\rho`$	$\approx 0.37 \text{ eV}$ 14. Ans: (b) Sol: Given, 2 wires $\therefore$ W <sub>1</sub> & W <sub>2</sub> d <sub>2</sub> = 2d <sub>1</sub> where d = diameter of wire L <sub>2</sub> = 4L <sub>1</sub> where L = length of wire Relation between resistances of W <sub>1</sub> & W <sub>2</sub> R = $\frac{\rho.L}{A} = \frac{\rho L}{\pi r^2}$ r = $\frac{d}{2}$ R = $\frac{\rho.L}{A} = \frac{4\rho L}{\pi r^2}$ R $\propto \frac{L}{t^2}$
	$R = \frac{\rho.L}{\pi \frac{d^2}{4}} = \frac{4\rho L}{\pi d^2} \qquad R \propto \frac{L}{d^2}$ clearing Sessions   Free Online Test Series   ASK an expert able 1M  3M  6M  12M  18M and 24 Months Subscription Packages

$$\frac{R_1}{R_2} = \frac{\frac{L_1}{d_1^2}}{\frac{L_2}{d_2^2}} = \frac{L_1}{d_1^2} \times \frac{d_2^2}{L_2} = \frac{L_1}{d_1^2} \times \frac{(2d_1)^2}{4L_1}$$
$$\implies \frac{R_1}{R_2} = 1 \qquad \therefore R_1 = R_2$$

## 15. Ans: (c)

**Sol:** Hall voltage, V<sub>H</sub> is inversely proportional to carrier concentration

$$\Rightarrow \frac{V_{H2}}{V_{H1}} = \frac{P_1}{P_2} = \frac{P_1}{2P}$$
$$\therefore V_{H2} = \frac{1}{2}V_{H1}$$

## 16. Ans: (b)

Sol:  $\frac{D}{\mu} = \frac{kT}{q} = V_T$   $\therefore D = \frac{0.36 \times 1.38 \times 10^{-23} \times 300}{1.6 \times 10^{-19}}$   $= 9.315 \times 10^{-3} \text{ m}^2/\text{sec}$ Diffusion length,  $L = \sqrt{D\tau}$   $= \sqrt{9.315 \times 10^{-3} \times 340 \times 10^{-6}}$  $= 1.77 \times 10^{-3} \text{ m}$ 

## 17. Ans: (a)

**Sol:** In intrinsic semiconductor, Number of electron = Number of holes

## 18. Ans: (a, b, c & d)

Sol: (a) Continuity equation for holes is given by

$$\frac{\partial p}{\partial t} = -\frac{1}{q} \frac{\partial J_p}{\partial x} + G^1 - \frac{\delta p}{\tau}$$

Similarity continuity equation for electrons is

$$\frac{\partial n}{\partial t} = \frac{1}{q} \frac{\partial J_n}{\partial x} + G^1 - \frac{\delta n}{\tau}$$

These equations describe the rate of change of minority carries with time.



India's Best Online Coaching Platform for GATE, ESE, PSUs, SSC-JE, RRB-JE, SSC, Banks, Groups & PSC Exams Enjoy a smooth online learning experience in various languages at your convenience

- Electronic Devices
- (b) Einstein's equation  $\frac{D_n}{\mu_n} = V_T \text{ and } \frac{Dp}{\mu p} = V_T \rightarrow \text{Diffusion}$
- constant and mobility are related (c) Poisson's equation is given by

$$\frac{\partial^2 v}{\partial r^2} = \frac{-\rho}{\epsilon}$$
 and  $E = \frac{-\partial v}{\partial r}$ 

charge density and electric field are related

(d) Diffusion equation

$$J_{P_{Diff}} = -qD_P \frac{dp}{dx} and J_{n_{Diff}} = qD_n \frac{dn}{dx}$$

Rate of change of carrier concentration in the space.

## 19. Ans: (a)


Sol: In P-type, as doping increases hole concentration p increases. According to mass action law  $n_p = \frac{n_i^2}{p_p} \implies$  electron concentration decreases.


## 20. Ans: (b)

Sol: In intrinsic semiconductor, electron hole pairs are generated due to external energy  $\Rightarrow$  true. electron mobility is 2 to 3 times more than hole mobility  $\Rightarrow$  true. Both the statements are true but statement II is not a correct explanation of statement I.

## 21. Ans: (a)

**Sol:** Both Statement (I) and Statement (II) are true and Statement (II) is the correct explanation of Statement (I).






Engineering Publications	6 Electronic Devices			
:. $I = \frac{5.5 - 0.498}{20}$ = 0.2501 $\Rightarrow$ 250 mA	To maintain constant current $\frac{(V_2 - 700 \text{mV})}{(40 - 20)} \frac{\text{V}}{^{\circ}\text{C}} = -2.5 \times 10^{-3} \frac{\text{V}}{^{\circ}\text{C}}$			
08. Ans: (a)	$\rightarrow$ V <sub>2</sub> = 650 mV			
<b>Sol:</b> Given $I_2^1 = I_1 \times 32$ Given $T_1 = 40^{\circ}C$ $T_2 = ?$	<b>10.</b> Ans: (b) Sol: $C = \frac{\varepsilon_0 \varepsilon_r A}{d} \Rightarrow \frac{C}{A} = \frac{\varepsilon_0 \varepsilon_r}{d}$			
$I_{2}^{1} = I_{1} \left( 2^{\frac{T_{2} - T_{1}}{10}} \right)$	$= \frac{11.7 \times 8.85 \times 10^{-12}}{10 \times 10^{-6}}$			
$I_{1} \times 32 = I_{1} \left( 2^{\frac{T_{2} - T_{1}}{10}} \right)$ $2^{5} = 2^{\frac{T_{2} - T_{1}}{10}}$	$= 10.36 \mu\text{F/m}^2$			
$\Rightarrow \frac{T_2 - T_1}{10} = 5$	11. Ans: (a, b & c) Sol: $V_b = E_{Fn} - E_{Fi} + E_{Fi} - E_{FP}$			
$T_2 - T_1 = 50$ $T_2 = 90^{\circ}C$ $T_2 = 50 + T_1$	$= \frac{\mathrm{KT}}{\mathrm{q}} \ell \mathrm{n} \left( \frac{\mathrm{N}_{\mathrm{D}}}{\mathrm{n}_{\mathrm{i}}} \right) + \frac{\mathrm{KT}}{\mathrm{q}} \ell \mathrm{n} \left( \frac{\mathrm{N}_{\mathrm{A}}}{\mathrm{n}_{\mathrm{i}}} \right)$ $\mathrm{KT} \left[ \mathrm{N} \mathrm{N} \right]$			
09. Ans: (b)	$\mathbf{V}_{\mathrm{b}} = \frac{\mathrm{KT}}{\mathrm{q}}  \ell \mathrm{n} \left  \frac{\mathrm{N}_{\mathrm{A}} \mathrm{N}_{\mathrm{D}}}{\mathrm{n}_{\mathrm{i}}^{2}} \right $			
Sol: For either Si (or) Ge $\frac{dV}{dT} \cong -2.5 \text{ mV}/^{0}\text{C}$	$N_{A} \And N_{D} \uparrow \rightarrow \frac{KT}{q} \ell n \left[ \frac{N_{A}N_{D}}{n_{i}^{2}} \right] \uparrow \rightarrow V_{b} \uparrow$			
Since 1995				
ACE				



# **Zener Diode**




	ACE
35K	Engineering Publications

$$R = \frac{7 \times 10^3}{500}$$
$$R = \frac{70}{5}\Omega \quad R = 14\,\Omega$$

## 06. Ans: (c)

Sol: Given circuit,



## 07. Ans: (a)

**Sol:** The ideal characteristic of a stabilizer is constant output voltage with low internal resistance.

## 08. Ans: (a)

## Sol:

- In PN junction diode break down depends on doping. As doping increases breakdown voltage decreases.
- In Zener diode breakdown is less than 6 V.
- It has Negative Temperature coefficient (operate in R. B)
- Avalanche diode breakdown greater than 6 V.

## 09. Ans: (b)

**Sol:** 'A' is correct and 'R' is correct but 'R' is **Not** the correct explanation of 'A' because DC voltage stabilizer circuit can be implemented by using other components like Op-Amp also. There is no need that only Zener diode to be used.

A ace online Since 1995

Chapter **2** S

## **Special Purpose Diodes**

## 01. Ans: (a)

Sol: Tunnel diode

It is highly doped S.C  $(1:10^3)$ 

It is an abrupt junction (step) with both sides heavily doped made up of Ge (or) GaAs .

It carries both majority and minority currents.

It can be used as oscillator

Operate in Negative Resistance region

Operate as fast switching device .

## 02. Ans: (c)


Sol: The values of voltage (V<sub>D</sub>) across a tunneldiode corresponding to peak and valley currents are V<sub>P</sub> and V<sub>V</sub> respectively. The range of tunnel-diode voltage V<sub>D</sub> for which the slope of its I-V<sub>D</sub> characteristics is negative would be V<sub>P</sub>  $\leq$  V<sub>D</sub> < V<sub>V</sub>.

## 03. Ans: (c)

**Sol:** Schottky diode is made of metal and semiconductor to decrease the switching times, hence it can be used for high frequency applications.

## 04. Ans: (a)

#### Sol:



## 05. Ans: (a)

Sol: The tunnel diode has a region in its voltage current characteristics where the current decreases with increased forward voltage known as its negative resistance region. This characteristic makes the tunnel diode useful in oscillators and as a microwave amplifier. **Bipolar Junction Transistor** 

01. Ans: (b) 05. Ans: (a) **Sol:** Given  $\alpha = 0.995$ ,  $I_E = 10mA$ , **Sol:**  $\alpha = \beta/(1+\beta) = 0.9803$  $I_{co} = 0.5 \text{mA}$  $\alpha = \beta^* \gamma^*$  $I_{CEO} = (1 + \beta) I_{CBO}$  $\rightarrow \beta^* = 0.9803/0.995$  $I_{CEO} = \left(1 + \frac{\alpha}{1 - \alpha}\right) I_{CBO}$ = 0.985202. Ans: (d)  $I_{CEO} = (1+199) \times 0.5 \times 10^{-6}$ Sol:  $I_C = 4mA$  $I_{CEO} = 100 \mu A$  $r_0 > 20k\Omega$ 06. Ans: (a)  $r_0 = \frac{V_A}{L}$ Sol:  $I_{CBO}$  is equal to  $I_{CO}$ . Reverse leakage current double for every Ten degrees rise in  $\frac{V_A}{I_C} > 20k\Omega$ temperature.  $V_A > 20k\Omega \times I_C$ 07. Ans: (b) Sol: Given base width  $W_B = 50 \times 10^{-6}$  cm  $V_A > 20 \times 10^3 \times 4 \times 10^{-3}$ Base doping  $N_B = 2 \times 10^{16} \text{ cm}^{-3}$  $\in_{r} \in_{0} = \in \& \in = 10^{-12} \text{ F/cm}$  $V_{\Delta} > 80$ 03. Ans: (b) **Sol:**  $V_A = 100 V$ Since 1995  $I_C = 1 \text{ mA}$  $V_{CF} = 10 V$  $I_{CQ}\left(1+\frac{V_{CE}}{V_{CE}}\right) = I_{C}$ 08. Ans: (a) If  $V_A \rightarrow \infty$ **Sol:**  $\alpha = 0.98$  $\Rightarrow I_C = I_{CO} = 1 \text{mA}$ 04. Ans: (b) Sol: The phenomenon is known as "Early

Effect" in a bipolar transistor refers to a

reduction of the effective base-width caused

by the reverse biasing of the base-collector

 $V_{\text{punch}} = \frac{qN_BW_B^2}{2c}$  $=\frac{1.6\times10^{-19}\times2\times10^{16}\times(50\times10^{-6})^2}{2\times10^{-12}}$  $V_{\text{punch}} = \frac{1.6 \times 2 \times 2500}{2} \times 10^{-3} = 4 \text{V}$  $I_{\rm B} = 40 \ \mu A$  $I_{CBO} = 1 \ \mu A$  $\beta = \frac{\alpha}{1 - \alpha} = \frac{0.98}{1 - 0.98} = 49$ For a CE active BJT  $I_{C} = \beta I_{B} + (1+\beta) I_{CBO}$  $=49 \times 40 \times 10^{-6} + 50 \times 10^{-6}$ = 2.01 mA



junction.

Chapter

#### **ACE** Engineering Publications


## **Postal Coaching Solutions**

### 09. Ans: (b)

Sol:  $I_{CBO} = 0.4 \ \mu A$   $I_{CEO} = 60 \ \mu A$   $I_{CEO} = (1+\beta) \ I_{CBO}$   $1 + \beta = \frac{I_{CEO}}{I_{CBO}}$   $= \frac{60}{0.4} = 150$   $\beta = 150 - 1 = 149$  $\alpha = \frac{\beta}{1+\beta} = \frac{149}{150} = 0.993$ 

### 10. Ans: (c)

**Sol:** Variation of base width due to reverse biased voltage across collector - base junction is known as "Early Effect".



As  $V_{CB}$  increases, effective base width  $(W'_B)$  decreases.

## 11. Ans: (b, c & d)

Sol: Condition for saturation

$$\beta \left[ \frac{V_{BB} - V_{BE}}{R_{B}} \right] \ge \frac{V_{CC} - V_{CE(set)}}{R_{C}}$$

$$50 \left[ \frac{5 - 0.7}{50 \times 10^{3}} \right] \ge \frac{10 - 0.2}{Rc}$$

$$4.3 \text{ mA} \ge \frac{9.8 \text{ v}}{R_{c}} \Longrightarrow R_{c} \ge \frac{9.8 \text{ v}}{4.3 \text{ mA}}$$

 $\Rightarrow\!R_{C}\!\geq\!2279.07\Omega$ 

## 12. Ans: (a)

**Sol:** Both Statement (I) and Statement (II) are true and Statement (II) is the correct explanation of Statement (I).

At very high temperature, extrinsic semiconductors will behave as intrinsic i.e., charge carriers will remains constant.

## 13. Ans: (b)

Sol:			
Junctio		ction	Region of operation
	E - B	C - B	-
NGA	F. B	F.B	Saturation Region
	F.B	R.B	Active Region
	R.B	F.B	Inverse active
	R.B	R.B	Region Cut-off Region

## 14. Ans: (c)

1995

Since

Sol: High power transistors are made of Si to withstand high temperature


: Silicon is an indirect band gap material.

|--|

11

**Junction Field Effect Transistor** 

Chapter




Engineering Publications	Postal Coaching Solutions
$V_{DS}$ at which pinch-off region means $(V_{DS})_{min} = V_{GS} - V_P$ = -5 - (-8)	<b>11.</b> Ans: (a) Sol: $g_{m0} = \left  \frac{2I_{DSS}}{V_p} \right  = \frac{2 \times 25 \times 10^{-3}}{10} = 5$
= -5 + 8 = 3 V <b>08.</b> Ans: (d) Sol: P. Voltage controlled device -FET (3) Q. Current controlled device -BJT (1) R. Conductivity modulation device IMPATT diode (4) S. Negative conductance device -UJT (2)	12. Ans: (b) Sol: BJT is current controlled current source $(R_i = 0; R_o = \infty)$ Gain × B.W is high FET is voltage controlled current source $(R_i = \infty; R_o = 0)$ Gain × B.W is low
<b>09.</b> Ans: (d) <b>Sol:</b> $I_{DSS} = 12 \text{ mA}$ $V_P = -6 \text{ V}$ $V_{GS} = 0 \text{ V}$ $V_{DS} = 7 \text{ V}$ At $V_{GS} = 0\text{ V}$ , $I_D = I_{DSS}$ $= 12\text{mA} \left( \because I_D = I_{DSS} \left( 1 - \frac{V_{GS}}{V_P} \right)^2 \right)$	<ul> <li>W UJT is a negative resistance device and can be used as an oscillator UJT can be used as switch but can't be amplification.</li> <li>13. Ans: (a)</li> <li>Sol: In FET majority carriers only exist. In BJT majority &amp; minority carriers exist.</li> </ul>
10. Ans: (d) Sol:	14. Ans: (a) Sol: G $D$ $N$ - channel FET 1995 $S$ Input resistance of FET is of the order of tens (or) hundreds of mega ohms (M $\Omega$ s) : $V_{gs}$ is reverse bias. : In reverse bias very small leakage current $I_{CO}$ flows through the gate.



Chapter 7

## **Optoelectronic Devices**



## 03. Ans: (b)

**Sol:** Avalanche photo diodes are preferred over PIN diodes in optical communication because Avalanche photo diodes are (APDs), extracted from avalanche gain and excess noise measurement and higher sensitivity. PIN diodes generate more noise.

## 04. Ans: (c)

Sol: Photo diode always operates in reverse bias. When no light falls on photo diode, Small amount of reverse saturation current flows through the device called "dark current".

## 05. Ans: (a)

Sol: Give,

$$E_{g} = 1.12 \text{ eV},; \lambda_{1} = 1.1 \text{ } \mu\text{m}$$

$$\lambda_{2} = 0.87 \text{ } \mu\text{m}; E_{g2} =?$$

$$E_{g} = \frac{12400 \text{ A}^{0}}{\lambda} \Rightarrow E_{g} \alpha \frac{1}{\lambda}$$

$$\frac{E_{g_{1}}}{E_{g_{2}}} = \frac{\lambda_{2}}{\lambda_{1}}$$

$$E_{g_2} = E_{g_1} \times \frac{\lambda_1}{\lambda_2} = 1.12 \times \frac{1.1}{0.87}$$
$$= 1.416 \text{ eV}$$

06. Ans: (a)

**Sol:** Sensitivity of photo diode depends on light intensity and depletion region width.

07. Ans: (d)

**Sol:** 
$$I_D = \frac{24 - 1.8}{820} = 0.02707 \text{ A} = 27.07 \text{ mA}$$

08. Ans: (c)

**Sol:** Photo diode operate in R.B: Photo diode works on the principle of photo electric effect.

A ace online

 $= 0.01111 \times 10^{3}$ 

 $= 11.11\Omega$ 

	ACE Engineering Publications	15		<b>Postal Coaching Solutions</b>
09. Sol:	<b>Ans: (b)</b> Voltage across PN junction diode resulting in current which in turn produce photons and light output. This inversion mechanism also called injection electro luminescence observed in LED's.	g s 1	13. Sol:	Ans: (d) LED: F.B Photo diode: R.B Zener diode: R.B Ordinary diode: F.B Tunnel diode: F.B
10. Sol:	<b>Ans: (b)</b> $\lambda = 890 \text{ A}^{\circ}$ $1.24 \times 10^{-6}$			Variable capacitance diode: R.B Avalanche diode: R.B
	$\lambda = \frac{1.24 \times 10^{-6}}{E_{G}} m$ $= \frac{1.24 \times 10^{-6}}{890 \times 10^{-10}}$ $= 13.93 \text{ eV}$		14. Sol: VG	Ans: (c) Tunnel diode is always operated in forward bias and light operated devices are operated in reverse bias. (Avalanche photo diode).
11. Sol:	<b>Ans: (d)</b> Solar cell converts optical (sunlight) energy into electrical energy.		15. Sol:	Ans: (b) LED's and LASER's are used in forward bias. Photo diodes are used in reverse bias.
12. Sol:	Ans: (b) R = 0.45  A/W $P_0 = 50 \mu W$ $R = \frac{I_P}{P_0}$ $I_P = R P_0$ $= 0.45 \times 50$ $= 22.5 \mu A$ Load current $= I_P + I_0$ $= 22.5 \mu A + 1\mu A$ $= 23.5 \mu A$	ce 1	99	



# MOSFET

01. Ans: (c) Sol:  $V_T = 1$  $V_{DS} = 5 - 1 = 4 V$  $V_{GS} = 3 - 1 = 2 V$  $V_{GS} - V_T = 2 - 1 = 1 V$  $V_{DS} > V_{GS} - V_T$  $4 > 1 \rightarrow$  Saturation

## 02. Ans: (d)

**Sol:** In active region (or) saturation region, channel is pinched off. Number of carriers present in the channel decreases from source end to drain end due to potential increases from source to drain.

03. Ans: (d)

Sol: 
$$\frac{I_{D_2}}{I_{D_1}} = \frac{K_n [V_{GS2} - V_T]^2}{K_n [V_{GS1} - V_T]^2}$$
$$\frac{I_{D_2}}{1 \text{ mA}} = \frac{[1400 - 400]^2}{[900 - 400]^2}$$
$$I_{D_2} = 4 \text{ mA}$$

## 04. Ans: (d)

Sol:  $A = 1 \text{ sq } \mu m = 10^{-12} \text{ m}^2$   $d = 1 \ \mu m = 1 \ \times 10^{-6} \text{ m}$   $N_D = 10^{19}/\text{cm}^3$   $n_i = 10^{10}$ No. of holes = concentration × volume Volume = A × d = 10^{-18} \text{ m}

$$p = \frac{n_i^2}{n} = \frac{10^{20}}{10^{19}}$$
  
= 10 holes / cm<sup>3</sup> = 10 × 10<sup>6</sup> holes / m<sup>3</sup>  
∴ No. of holes = 10 × 10<sup>6</sup> × 10<sup>-18</sup>

 $= 10^{-11}$  holes  $\approx 0$ 

## 05. Ans: (b)

- Sol: 1) since it has n-type source & drain, it is n-channel MOSFET.
  - 2) Drain current flows only when  $V_{GS} > 2V$ , it implies it has threshold voltage (V<sub>th</sub>) of +2V

 $\Rightarrow$  It is enhancement type MOSFET.

3) 
$$V_{Th} = +2V$$
  
4)  $g_m = \mu_n C_{ox} \frac{W}{I} [V_{GS} - V_{Th}],$ 

transconductance depends upon electron mobility.

06. Ans: (b)

**Sol:** 
$$C_{sbo} = \frac{\epsilon_{si} A}{d}$$

Since


19

d = 10 nm

$$= 11.7 \times 8.9 \times 10^{-12} \, \text{F/m}$$

$$A = (0.2\mu \times 1\mu) + (0.2\mu \times 1\mu) + (0.2\mu \times 1\mu)$$
  
= 3(0.2\mu \times 1\mu) = 0.6 \times 10^{-12} m<sup>2</sup>  
$$C_{sbo} = \frac{11.7 \times 8.9 \times 10^{-12} \times 0.6 \times 10^{-12}}{10 \times 10^{-9}}$$
$$C_{sbo} = 6.24 \times 10^{-15}$$
  
\approx 7 fF





online	Affordable Fee	Available 1

able Fee | Available 1M |3M |6M |12M |18M and 24 Months Subscription Packages

#### ACE Engineering Publications

Since 1995

### **Electronic Devices**


- 12. Ans: (a & c) Sol:  $X_{dmax} = \sqrt{\frac{2 \in_{s} \phi_{t}}{qN_{A}}} = \sqrt{\frac{4 \in_{s} \phi_{F}}{qN_{A}}}$   $\phi_{F} = V_{t} \ln\left(\frac{N_{A}}{n_{t}}\right) = 0.026 \ln\left(\frac{10^{15}}{1.5 \times 10^{10}}\right)$  = 0.29V  $X_{dmax} = \sqrt{\frac{4 \times 11.7 \times 8.854 \times 10^{-14} \times 0.29}{0.6 \times 10^{-19} \times 10^{15}}}$   $= 8.67 \times 10^{-5} \text{ cm} = 8.67 \times 10^{-7} \text{ m} = 0.867 \mu \text{m}}$   $|Q_{dinv}| = qN_{A} X_{dmax}$   $= 1.6 \times 10^{-19} \times 10^{15} \times 0.867 \times 10^{-5}$   $= 1.39 \text{ nc/cm}^{2}$   $C_{ox} = \frac{\epsilon_{ox}}{t_{ox}} = \frac{3.9 \times 8.854 \times 10^{-14}}{10 \times 10^{-7}}$   $= 3.45 \times 10^{-7} \text{ F/cm}^{2} = 0.345 \ \mu \text{F/cm}^{2}$   $V_{T} = \frac{|Q_{dinv}|}{C_{ox}} + Q_{t} = \frac{|Q_{dinv}|}{C_{ox}} + 2\phi_{F}$   $= \frac{1.39 \times 10^{-9}}{0.345 \times 10^{-6}} + 2 \times 0.29$ = 0.58V
- 13. Ans: (a, c & d)

Sol: 
$$V_{TH} = \frac{\sqrt{2qN_A \in_s (2\phi_B)}}{C_{ox}} + 2\phi_B + V_{BF},$$
  
 $C_{ox} = \frac{\epsilon_{ox}}{t_{ox}}$ 

As  $V_{TH}$  is proportional to channel dopant concentration and gate-oxide thickness.

 $\therefore$  V<sub>TH</sub> can be increased by increasing channel dopant concentration & gate-oxide thickness and also V<sub>TH</sub> can be increased by increasing channel length.







 Regular Live Doubt clearing Sessions
 Free Online Test Series | ASK an expert


 Affordable Fee
 Available 1M |3M |6M |12M |18M and 24 Months Subscription Packages

ace online




Engineering Publications	21	Postal Coaching Solutions
$C_{2} = C_{gd} \left( 1 - \frac{1}{A_{v}} \right),$ $A_{v} = \text{mid-band},$ $gain = g_{m}(r_{d}   R_{D}  R_{L}) = -16.66$		$V_{GS_2} = V_{G_1} - V_S$ = V_0 - 0 = V_0 $\left(\frac{W}{L}\right)_1 (5 - (V_0) - 0.8)^2 = \left(\frac{W}{L}\right)_2 (V_0 - 0.8)^2$ V_0 = 2.5V
$-\underbrace{\overset{R_{eq}}{\rule{0pt}{2.5pt}}}_{C_{eq}}$		<b>02.</b> Ans: (a) Sol: $\left(\frac{W}{L}\right)_1 \left(V_{GS_1} - V_T\right)^2 = \left(\frac{W}{L}\right)_2 \left(V_{GS_2} - V_T\right)^2$
$C_2 = 2pF\left(1 - \frac{1}{-16.66}\right) = 2.12 pF$	RIA	40 $(4.2 - V_0)^2 = 15(V_0 - 0.8)^2$ $V_0 = 2.91 \text{ V}$ 03. Ans: (c)
$f_{\rm H} = \frac{1}{2\pi C_{\rm eq} R_{\rm eq}}$ C <sub>eq</sub> = 1 + 2.12 = 3.12 pF, R <sub>eq</sub> = 8.33kΩ		Sol: From figure $I_{DS1} = I_{DS2.}$ $\frac{1}{2} \mu_n C_{0x} \left(\frac{W}{L}\right)_1 (V_{GS_1} - V_t)^2$
$\Rightarrow f_{\rm H} = 6.123 \times 10^6  \text{Hz}$ <b>MOSFET BIASING</b>		$= \frac{1}{2} \mu_n C_{0x} \left( \frac{W}{L} \right)_2 (V_{GS_2} - V_t)^2$ 6V
01. Ans: (b) Sol: $V_T = 0.8$ $K_n = 30 \times 10^{-6}$ Sin	ce 1	$I_{DS1}$ $M_1$ $\left(\frac{W}{L}\right)_1 = 4$
$ \begin{pmatrix} \frac{W_1}{L} \\ 1 \end{pmatrix}_1 = \begin{pmatrix} \frac{W}{L} \\ 1 \end{pmatrix}_2 = 40 $ $ V_{D_1} = +5 $ $ I_{D_1} = I_{D_2} $		$I_{DS2}$ $M_2$ $\left(\frac{W}{L}\right)_2 = 1$
$\frac{1}{2}\mu_{n} C_{ox} \left(\frac{W}{L}\right)_{1} \left(V_{GS_{1}} - V_{T}\right)^{2}$		$\downarrow$ $\therefore 4(5 - V_x - V_t)^2 = 1(V_x - V_t)^2$
$= \frac{1}{2} \mu_n C_{ox} \left( \frac{W}{L} \right)_2 (V_{GS_2} - V_T)^2$ $V_{GS_1} = V_{D_1} - V_0$ $= +5 - V_0$		$(:: V_{GS1} = V_G - V_x = 5 - V_x)$ $\Rightarrow 2(5 - V_x - V_t) = (V_x - V_t)$ $\therefore V_x = 3V$
	clearin	g Sessions   Free Online Test Series   ASK an expert







CMOS & Device Technology



Chapter